

P2-kaartstation met vijf P2-kaartsleuven en USB 2.0/IEEE 1394b-interfaces

AJ-PCD20

High speed data transfer to Windows PC/Mac based Nonlinear Editor
Install the P2 drive into a 5 type bay on a desktop PC
With the AC adaptor, you can use it as a stand-alone external drive
USB2.0/IEEE 1394b Interface
P2 Card Drive with Five P2 card Slots.
Please click here for a list of operation manuals to download.



- Gegevensoverdracht met hoge snelheid naar op Windows PC/Mac gebaseerde niet-lineaire editor
- Installeer het P2-station in een sleuf van het type 5 op een desktopcomputer
- Met de AC-adapter kunt u deze gebruiken als een onafhankelijk extern station
- USB2.0/IEEE 1394b-interface

P2-kaartstation met vijf P2-kaartsleuven.

[Klik hier](#) voor een lijst met downloadbare gebruiksaanwijzingen.

SPECIFICATIONS

URL: <https://business.panasonic.nl/professional-camera/aj-pcd20>

CONTACT

Web: <https://business.panasonic.nl/professional-camera/contact-us>